

Firmware Upgrade Procedure for DVD Recorder DVR900E

STEP ONE:

If you received this by download or email then you need to burn the attached files to a CD-R before proceeding.

Do not burn this PDF file to the CD-R.

NOTE: The disc must be burnt as a data disc and ISO9660 file format is recommended, not Joliet or UDF. Finalize the disc when it is burnt. Do not leave it as an open session.

STEP TWO:

The unit must be properly connected to the television to perform an upgrade. Confirm that the unit is connected to the television by pressing the setup button on the remote control; the setup menu should appear on the screen.

****First, determine which Firmware version is installed on your unit by:***

1. Powering on the unit by pressing the [**POWER**] button. (if you have the combo unit, the machine should be on the DVD side). Wait until it completes reading. Ensure that there is no disc in the machine.
2. Pressing the [**CM SKIP**] button the remote control, then press [**1**], [**2**], AND [**3**].
-You should see the configuration settings of the unit appear, which look similar to Fig 1 below.

Fig. 1



Please note the area that says FE: this stands for the front end software.

FE: NRS** represents the version.**

STEP THREE:

To upgrade....

1. Press the [**CM SKIP**] on the remote control, then press [**6**], [**5**], and [**4**]. (if a you have the combo unit, the machine should be on the DVD side)
2. The tray will automatically open. Insert the firmware disc then and close the tray. The unit will automatically write in the new information. After the update is completed the tray opens automatically.
3. Remove the disc, and then press [**POWER**] to turn the unit off.
4. Unplug for 30 seconds then reconnect. Press the [**POWER**] button again to resume normal operation with upgrade complete.

WARNING:

DO NOT POWER THE UNIT OFF DURING THE UPGRADE PROCESS. THIS WILL PERMANENTLY DAMAGE THE MACHINE.

DO NOT APPLY INCORRECT FIRMWARE DISC. USING THE WRONG DISC WILL CAUSE A PERMANENT ERROR.